JIANGHAO GENERATOR





Genset

Model	JHK5-725GF
Voltage	230/400V
Frequency&Speed	50HZ;1500RPM
Prime Power	580kW/725kVA
Standby Power	640kW/800kVA
Compression Ratio	o: 14.5:1
Bore:	159 mm
Storke:	159 mm

Emission Certification:

Governor Regulation: $\leq 3\%$





Alternator

Pole No.	4-Pole
Exciter Type	Single bearing, Brushless,
	Self-excited
Power factor	0.8
Voltage adjust range	\leq 5%
Insulation Grade	Н
Protection Grade	IP23/22
Phase / wire	3 phase 4 wires

▶ Engine: Cummins KT38-GA

Alternator:Stamford/Leroy Somer


/Hengsheng

➤Controller:DeepSea/SmartGen/DEIF

/ComAp

Aspiration:	Tu
Displacement	381
No.of Cylinders	12
Fuel System	Cu

Turbocharged 38L 12 Cummins PT



- NEMAMG1.JIANGHAO, and ANSI standards compliance for temperature rise and motor starting.
- ♦ Sustained short-circuit current of up to 300
- % ~ of the rated current for upto 10 seconds.
- Sustained short-circuit current enabling down stream circuit breakers to trip without collapsing the generator field.
- $\diamond \quad {\sf Self-ventilated and dripproof construction}.$
- Superior voltage waveform from two-thirds pitch windings and skewed stator.
- Digital solid-state.volts-per-hertz voltage regulator with +1% no-load to full-load regulation.



Control Panel

Engine hours run.



The control module gives digital readouts of: Generator voltage; Output frequency; Engine speed; Battery voltage;



Dimension:4300*1800*2500mm Weight:7100kg



Dimension:5800*2300*2550mm Weight:11000kg Fuel Tank Capacity:1200L The **control panel** is an Digital Control Module suitable for a wide variety of single, diesel or gas, gen-set applications.

Monitoring an extensive number of engine parameters, the module will display warnings, shutdown and engine status information on the back-lit LCD screen and illuminated LEDs.

The control module has indicators for failure information:

Over speed/Low speed, Emergency stop Low oil pressure; High water temperature Failure to start Battery charger failure

Automatic shutdown occurs under:

Low engine oil pressure; High engine water temperature; Over speed/Low speed; Failure to start after three attempts.

Electrical system

- Maintenance-free and anti-explosion battery
- Standard breaker
- ABB breaker (optional)
- ATS (optional)
- Battery charger (optional)
- GMS monitoring (optional)

Packing

- Wrapping film packaging
- Tray packaging
- plywood box packaging

Jiangsu Jianghao Generator Co.,Ltd

Address: No.1 Xixu Road, Medical High-tech Zone,

Taizhou city, Jiangsu, China Contact Person: Anthony Feng Email: <u>ihfsale@jhgenerator.com</u> WhatsAPP: +86 18652649673

